

(4) *Additional certifications or requirements.* None.

§ 627.52 Class III biological safety cabinet.

(a) *Description.* These cabinets (figure H-III in appendix F to this part) are totally enclosed, ventilated cabinets of gas-tight construction. Operations are conducted through attached rubber gloves. The supply of air is drawn into the cabinet through HEPA filters. The exhaust air is treated by double HEPA filtration, or by HEPA filtration followed by incineration, and is not allowed to recirculate within the room.

(b) *Uses.* These cabinets provide the ultimate protection for personnel. They are suitable for low, moderate, and high-risk etiologic agents.

(c) *Prohibitions.* More than minute amounts of flammables must not be used in these cabinets.

(d) *Certifications and requirements.* (1) These cabinets will have a manometer or magnehelic gauge that indicates the negative pressure that is maintained inside the cabinet. The pressure inside the cabinet should be a minimum of 0.5 inches water gauge negative to the surrounding room.

(2) These cabinets will be pressure tested by the soap bubble or halogen leak test as prescribed in NSF Standard No. 49, appendix B1 (latest revision, June 1987), and certified, when the HEPA filter units are serviced.

§ 627.53 Fume hood.

Fume hoods in which etiologic agents are handled must use proven technologies to provide optimal containment. Fume hood placement, design, and capture testing requirements for use in designing new laboratories can be found in the latest edition of Industrial Ventilation, A Manual of Recommended Practices, published by the American Conference of Governmental Industrial Hygienists.

(a) *Description.* Fume hoods are common chemical laboratory furnishings designed to capture fumes from chemicals that are used within them. Air is drawn through the opening and vented to the exterior without recirculation.

(b) *Uses.* Fume hoods provide excellent containment for handling hazardous chemicals.

(c) *Prohibitions.* Moderate risk biologicals and open containers of dry forms of toxins must not be used in a fume hood without HEPA filtration. Fume hoods should never be used when sterility is required.

(d) *Certification and requirements.* (1) Inward air flow will be an average of 100 plus or minus 20 lfpm as measured at the face of the fume hood. Proper function of laboratory hoods is not only a function of face velocity. An evaluation of the total operating environment is necessary.

(2) When filters are required, they will be certified by the mineral oil droplet (HEPA) or Freon (Charcoal) leak test as appropriate. Leakage through the filters will be less than 0.05 percent for Freon and 0.03 percent for oil droplets when initially installed.

(3) Fume hoods will be provided with indicator devices to give a warning should the ventilation system fail or if the hood face velocity falls below an average of 80 lfpm.

(4) Hood air flow will be certified when installed, when maintenance is performed on the ventilation system, and semiannually thereafter.

§ 627.54 Glove box.

(a) *Description.* A glove box is an enclosure that provides a positive barrier from liquids, solids, and chemical vapors. A glove box has viewing ports and glove ports for access. The box maintains personnel protection through solid barriers and maintenance of a negative pressure relative to its surroundings.

(b) *Uses.* Glove boxes are used when extreme containment is needed for highly toxic chemicals, especially for dry chemicals that can be swept out of containers by the airflow in hoods.

(c) *Prohibitions.* Unventilated boxes must not be used with volatile flammable materials and should be used with volatile toxic materials unless dilution ventilation is provided.

(d) *Additional certifications and requirements.* (1) The glove box will be maintained at a pressure of at least 0.25 inches water gauge less than its surroundings.

(2) The pressure differential will be indicated by a manometer or magnehelic gauge. Indicator devices